

Protocol & Procedure for Placement of the OCO Biomedical Macro™ Two-Stage Implant



Proper Drill Sequence for Macro™ Two-Stage Implant (6.0 diameters)

- 1 - #8 High-speed Surgical Bur** - Penetrate soft tissue if flapless, otherwise use to divot crest
- 2 - 1.8mm Pilot Drill** - Place drill stop onto pilot drill and drill full length stopping at soft tissue
- 3 - Paralleling Pin** - Place paralleling pin to evaluate implant size and trajectory
- 4 - Tissue Punch** - Remove soft tissue if placing implant flapless
- 5 - 1.8mm Pilot Drill** - Take pilot drill to full length of intended implant
- 6 - Final Drill** - Take final drill to full length of osteotomy*
- 7 - Internal Hex Driver** - Drive implant into final position **(MUST USE 4mm & 5mm drivers)**

*Macro™ implants must have osteotomy created by stepping up in serial progression

For questions on the Macro™ implant placement and restorative techniques please visit www.ocobiomedical.com, call 800-228-0477, +1 (505)-293-0025 international or email sales@ocobiomedical.com.

OCO Biomedical 
9550 San Mateo Blvd. NE, Suite C
Albuquerque, NM 87113
www.ocobiomedical.com

Toll Free: (800) 228-0477
International: + 1(505) 293-0025
Direct: (505) 293-0025
Fax: (505) 293-0447

Designed and Manufactured in USA 
U.S. Patent: US 8,277,218,B2
ISO 13485:2003 CERTIFIED

